

# BLE 232 PLUS

*taskit*


The new BLE232 PLUS converter from taskit GmbH enables a wireless connection between two RS232 interfaces via 2.4 Ghz radio.



Available with male and female connector



You can now use the configuration to switch between the two operating modes as "**peripheral**" and as "**central**" mode. Configure the BLE232 Plus via the serial interface with AT commands and send or receive the data.



**taskit GmbH**  
 Groß-Berliner Damm 37  
 12487 Berlin  
 030 611 295 0  
 info@taskit.de

